

Nortel CS1000 Basic Maintenance Commands

LD 22	
REQ PRT TYPE AHST	Request all of the available TTY/Error History.

LD 32	
.STAT 3	Get status of units on Card 3 of Small System
.ENLS 0 .ENLS 1 .ENLS 2 .ENLS 3 etc	Enable all cards and units in Small system shelves
.ENLC 3	Enable all units on card 3 in a small system
.ENLS 3 0	Enable all cards and units on Loop 3, Shelf 0 in a large system
.IDU 3 0	Identify digital phone connected to TN 3-0 in a small system. Will report if phone exists or not
.IDU 3 0 1 1	Identify digital phone connected to TN 3-0-1-1 in a large system. Will report if phone exists or not
.ENXP 7	Enable Controller 7. Must identify controllers from LD97, REQ PRT TYPE XPE
.DSXP 7	Disable Controller 7 (disables all phones in related shelf). Must identify controllers from LD97, REQ PRT TYPE XPE

LD 30	
.TEST	Test connectivity to all shelves/cards in a small system
.SHLF 3 0	Test connectivity to all cards on Shelf 3-0 of a large system
.LOOP 3	Test connectivity to all cards in Loop 3 of a large system
.LOOP all	Test connectivity to all IPE Cards in large system.

LD 96	
.STAT DCH	Get status of all D-Channels
.ENL DCH 2	Enable D-Channel 2
.DIS DCH 2	Disable D-Channel 2 (need to disable D-Channel before resetting/disabling related PRI loop)

LD 60	
.STAT	Get status of all PRI/Digital Trunk Loops
.DISL 8	Disable PRI/Digital Trunk Loop 8 (may need to disable D-Channel first)
.ENLL 8	Enable PRI/Digital Trunk Loop 8
.ENCH 8 1	Enable channel 1 of PRI/Digital Trunk Loop 8
.DSCH 8 1	Disable channel 1 of PRI/Digital Trunk Loop 8

LD 48	See books for Enable and Other LD48 Commands
.STAT ELAN	Symposium / Call Pilot Link
.STAM AML	Meridian Mail Link
.STAT TMDI	Option 11C TMDI card (T-1)