

WIRING THE NORTEL M2250 ATTENDANT CONSOLE




Figure 17
M2250 attendant console cross-connections

